


100**Figure 1**




Figure 2





Figure 3

**Figure 4**





Figure 5

**Figure 6**




Figure 7A




Figure 7B




Figure 8




Figure 9

1000

MVXL	Count	Destination	Source

Figure 10

1101. User calls Device Driver

- Supplies
 - Source Network ID
 - Source Offset
 - Destination Network ID

1102. Device driver transfers addresses to Adapter

1103. Adapter Translates Addresses

- Looks up Physical Base addresses from ID's (Table Lookup)
- Obtains Lock and current Destination Offset
- Adds offsets
- Checks bounds

1104. Adapter loads count and addresses in registers

1105. Adapter executes Data Move

1106. Adapter Frees Lock

1107. Adapter notifies device Driver which "Returns" to user

Figure 11

1201. User calls Device Driver

- Supplies
 - Source Network ID
 - Source Offset
 - Destination Network ID

1202. Device driver sends addresses to adapter

1203. Adapter Translates

- Looks up Physical Base addresses from ID's
(Table Lookup)
- Obtains Lock and current Destination Offset*
- Adds offsets
- Checks bounds
- Returns Lock and Physical addresses to
Device Driver

1204. Device Driver executes Data Move

1205. Device Driver Frees Lock

1206. Device Driver Returns

Figure 12







Figure 13

**Figure 14**

**Figure 15**

**Figure 16**